






CAUTION!

The quick start guide does not replace the original installation and operating manual!
Danger, Warning and Safety instructions in the original installation and operating manual must be respected!

The short menu allows a quick commissioning of the control unit. It contains only the listed steps. For more information on the single menu positions (steps), please refer to the main manual (see page references)!

You can enter the short menu by entering password 2 (factory setting: 9001). To change password please refer to the main manual, chapter „initial operation“, paragraph „passwords“ (menu 2570).


Power on the control unit




„Back“ in main menu
„Change parameters / values“ in submenus



„Select from selected parameters and confirm values / settings“ menu



„Next“ in main menu
„Change parameters / values“ in submenus



1

BACKWARD	
LANGUAGE ENGLISH LANGUAGE/LENGUA SELECTION	
FORWARD	0200

2

BACKWARD	
SET TIME	
FORWARD	0300

3

BACKWARD	
CHECK DIRECTION	
FORWARD	0400

4

BACKWARD	
END POSITIONS ADJUST	
FORWARD	500

5

BACKWARD	
MODE OF OPERATION IMPULSE UP/DEAD/DWN SELECT/CHANGE	
FORWARD	0700

6

BACKWARD	
SAFETY DEVICES SELECT	
FORWARD	1000

7

BACKWARD	
SHUTDOWN AUTOMATIC SET	
FORWARD	1500

8

BACKWARD	
GO TO OPERATION	
	3000

SOMMER Antriebs- und
Funktechnik GmbH

Hans-Böckler-Straße 21-27
73230 Kirchheim/Teck
Germany

info@sommer.eu
www.sommer.eu

© Copyright 2016
Alle Rechte vorbehalten.